


WIRELESS TRACKER EXPANSION BOARD RF KIT

DoorKing Part Number
1489-080


This wireless kit provides wireless communication for a 2358-010 tracker expansion board to a wireless baseboard in a access control system. Use wireless tracker expansion boards **ONLY** with DoorKing: 1833, 1835, 1837 and 1838 multi-door access controller access control systems. **DO NOT** use with 1838 Access Plus model.

Installation


Plug the 1489-010 board into the wireless connector and secure boards with 4 screws to the tracker expansion board. See the HARDwired tracker expansion board manual to connect desired options to terminals #1- #34 to manage a remote access point. **DO NOT CONNECT ANY WIRES TO TERMINALS #10, #17, #27, #28 or #29 (Used for HARDwire communication line ONLY)**. Power transformer must connect to tracker expansion board #33 and #34 (**REQUIRED**), see below for antenna options.



Typical Remote Access Point Installations



Other Antenna Options



Board Reference

DoorKing Part Number
1489-080

See "Wireless System Layout and Start-Up Procedure" for system layout limitations.

RF SECURE LED

UNPAIRED MODE:

Steady Red - Board is communicating with **unpaired** wireless baseboard.
Blinking Red - Board is **NOT** communicating with **unpaired** wireless baseboard.

PAIRED MODE:

Steady Green - Board is communicating with **paired** wireless baseboard.
Blinking Green - Board is **NOT** communicating with **paired** wireless baseboard.

Board Address (REQUIRED)
Connection to Wiegand 2: Addresses 03-10
Connection to Wiegand 1: Addresses 11-18
See HARDwire tracker expansion board manual for more information.

RF Range Adjustment

Set to max (full clockwise) for most applications. This may need to be dialed back to limit the range when using a repeater.

Program Button:

- Press after adjustment has been made to the **RF RANGE**, **RF ID** or **RF CH** before changes will take effect.
- Press and hold for 3 sec. to **PAIR** to wireless baseboard, may take up to 20 seconds to **PAIR**.
(**RF SECURE LED Paired** - steady **GREEN**).
- Press and hold **again** for 3 sec. to **UNPAIR** from wireless baseboard if necessary
(**RF SECURE LED Unpaired** - steady **RED**).

IMPORTANT Wiring and LED Note:

See HARDwire tracker expansion board manual for terminal #1 - #34 connections and LED descriptions.
DO NOT connect any wires to terminals #10, #17, #27, #28 and #29.

RF Data LED - Blinks when receiving a reply from wireless baseboard after a card code is sent.
RF Status LED - Not used.
Code Sent LED - Blinks after a card code has been sent to wireless baseboard.
Code Good LED - Blinks if the card code is in the database (access granted).
Code Bad LED - Blinks if the card code is **not** in the database (access denied).

RF Strength LED:

Updated every time a **RF SYNC** signal is received.
Green - Strong signal - **Normal**
Yellow - Marginal signal - May lose communication.
Red - Poor signal - **Unreliable**

RF SYNC LED:

Blinking Blue - Connected with wireless baseboard.
Blinking Rapidly - Pairing with wireless baseboard.
OFF - No signal with wireless baseboard.

Note: If LED lights for a couple of seconds after the reset button or program button is pressed, this indicates this board has been programmed to forward card codes for other boards (See program table).

RF LOST LED:

ON - Lost communication with wireless baseboard.
OFF - Communication is established with wireless baseboard.

Blinking Rapidly - Pairing with wireless baseboard.

RF ID **RF CH** **Important**
MUST be set to **SAME** ID number and channel number as the wireless baseboard.

Power Transformer

Power transformer is **REQUIRED** and is wired to terminals #33 and #34, wire polarity does not matter.
18 GA. Wire 100 ft max
16 GA. Wire 200 ft max

RESET Button - Press to reboot tracker expansion board AND the 1489 wireless board.

2358 Tracker Expansion Board

1489 Wireless Board

Programming

Basic Programming Sequence on EACH Board

Follow these basic steps to perform desired programming. See programming options table for **PROGRAM STEPS** on next page. **EACH** tracker expansion board in the system **MUST** be physically programmed.

1. Press **▼▲** arrow buttons or **ENT** button to **ACTIVATE** LED display.
2. Press **▼▲** arrow buttons again to **SELECT** desired **PROGRAM STEP**.
3. Press **ENT** button to **ENTER** desired **PROGRAM STEP**. (LED display number will blink after **ENT** button has been pressed).
4. Press **▼▲** arrow buttons to select **SELECTION NUMBER** for desired program step.
5. Press **ENT** button to program **SELECTION NUMBER** for desired program step. (Function has now been programmed into board).
6. Press **ENT** button again to exit programming **OR** after 10 seconds, board will automatically exit programming.

Note: Repeat these steps for all other desired programming functions for **THIS** tracker expansion board.
Each tracker expansion board will have to be **INDIVIDUALLY** programmed with desired functions.

IMPORTANT Display Decimal Point Note



When decimal point is displayed:
Indicates you are selecting a program step.

When decimal point is **NOT** displayed: Indicates you are **IN** a program step.

Programming Options on EACH Wireless Tracker Expansion Board

Program Step	Function	Options	Selection Number	Function Description	Factory Default
1	Door Strike Timer	00 - 99 MIN MAX	00 01 - 99	Sets Strike Time for Output Relay (term #25 & #26) 0.25 second strike time - MINIMUM Strike time in 1-second increments: 01 = 1 second, 99 = 99 seconds - MAXIMUM	01 (1 second)
2	Free Exit Timer, Strike Time	00 - 99 MIN MAX	00 01 - 99	Set Strike Time for RX of Output Relay (input at term #18) 0.25 second Egress Strike time - MINIMUM Egress Strike time in 1-second increments: 01 = 1 second, 99 = 99 seconds - MAXIMUM	01 (1 second)
3	Door Ajar Timer	01 - 99 MIN MAX	00 01 - 99	Timer starts when valid access has been granted 1 second Door Ajar Timer - MINIMUM Timer set in 5-second increments: 01 = 5 seconds, 10 = 50 seconds, 99 = 495 seconds - MAXIMUM	12 (60 seconds)
4	Aux Relay Timer	00 - 99 MIN MAX	00 01 - 99	Timer setting for Aux Relay activation 1 second Door Ajar Timer - MINIMUM Timer set in 5-second increments: 01 = 5 seconds, 10 = 50 seconds, 99 = 495 seconds - MAXIMUM	12 (60 seconds)
5	Not Used				
6	Not Used				
7	Not Used				
8	Door Contact Switch Logic	0 or 1	00 01 - 99	Sets Door Contact Switch for the type Door Lock connected to Output Relay N.O. - Normally Open: contact from door lock with Door Closed (typical - electric strike) N.C. - Normally Closed: contact from door lock with Door Closed (typical - maglock)	0 (N.O. w/door closed)
9	Not Used				
10	Not Used				
11	Hold Open or Hold Egress functions	0 or 1	0 1	Sets how Aux & Alarm Relays respond during Hold Open or Hold Egress situation No Aux Relay functions. Alarm will be in "Reset". If Alarm Relay is set for "Integral" mode, Alarm relay will not activate. If Alarm Relay set for "Bypass" mode, Alarm Relay will activate for Hold Open period or Extended Egress Hold. Aux Relay will function for all settings. If Alarm Relay is set for "Integral" mode, Alarm relay will not activate. If Alarm Relay set for "Bypass" mode, Alarm Relay will activate for Hold Open period or Extended Egress Hold.	0 (No Aux relay functions)
12	Not Used				
13	Not Used				
14	Not Used				
15	Aux Relay Functions	0 - 5	0 1 2 3 4 5	Sets function for Aux Relay (term #21 & #22) Aux Relay Disabled Door Ajar Timer: Requires Door Contact Switch. Aux Relay activates when Door Not Closed. Door Ajar Timer, Pulse: Requires Door Contact Switch. Aux Relay "pulses" when Door Not Closed. Door Ajar Timer: Requires Door Contact Switch. When door opens, start Door Ajar Timer. When timer expires Aux Relay activates for Aux Relay timer or until door closes, whichever occurs first. Door Ajar Timer, Pulse: Requires Door Contact Switch. When door opens, start Door Ajar Timer. When timer expires Aux Relay Pulses for Aux Relay timer or until door closes, whichever occurs first. Door Ajar, Pulse warning the ON: Requires Door Contact Switch. When door opens, Pulse Aux Relay and start Door Ajar Timer. When timer expires Aux Relay ON for Aux Relay timer or until door closes, whichever occurs first.	0 (Disabled)
16	Alarm Relay Functions	0 - 4	0 1 2 3 4	Sets function for Alarm Relay (term #23 & #24) See Door Operation Note below. Aux Relay Disabled Bypass Mode: Alarm Relay provides "Bypass" to Alarm Door Contact Switch. With proper door input (access or egress) activate Alarm Relay, start Strike timer and Door Ajar timer. When Door Ajar timer expires, deactivate Alarm Relay. If second Door Contact Switch is provided, generate transaction for Door Ajar and Door Closed following Door Forced condition. Also generate transaction for Door Forced condition. Integral Mode, Door Ajar Timer: Door Contact Switch connected to Tracker, Alarm Relay provides connection directly to Alarm System. When door is opened for any reason, start Door Ajar timer. When Door Ajar timer expires and Door is still OPEN, activate Alarm Relay. Reset when door closes. Send Door Ajar and Door Close transactions. Integral Mode, Proper and Forced condition: Door Contact Switch connected to Tracker, Alarm Relay provides connection directly to Alarm System. With proper door input (access or egress) start Strike timer and Door Ajar timer. When Door Ajar timer expires and Door is still OPEN, activate Alarm Relay. Reset when door closes. If door is opened without proper condition, activate alarm relay. When door closes deactivate Alarm Relay. Send Door Ajar, Door Close and Door Forced transactions. Gate Alarm Function: Alarm Relay will activate for 1 second when tracker board receives a "Gate Forced" or "Gate Obstructed" transaction from the operator control board.	0 (Disabled)
17	Not Used				
18	Not Used				
19	Reset to Factory Defaults	5	5	Sets all parameters to Factory Defaults.	
20	View RF POT Setting	Displays on LED Display		Sets maximum amount of allowable signal strength loss	
21	View RF Signal Loss	Displays on LED Display		Displays current signal loss between Base and Track	
22	Card Code Forwarding	0 or 1	0 1	Sets Wireless Tracker to act as Repeater ONLY USE AS DIRECTED BY DOORKING TECH SUPPORT Repeater Mode OFF Repeater Mode ON	0 (Off)

Important Notice Due to the nature of wireless communications, transmission and reception of data can never be guaranteed. Data may be delayed, corrupted (i.e., have errors) or be totally lost. Although significant delays or losses of data are rare when wireless devices are used in a normal manner with a well-constructed network, DoorKing wireless products should not be used in situations where failure to transmit or receive data could result in damage of any kind to the user or any other party, including but not limited to personal injury, death, or loss of property. DoorKing, Inc. accepts no responsibility for damages of any kind resulting from delays or errors in data transmitted or received using DoorKing wireless products, or for failure of DoorKing wireless products to transmit or receive such data.

Safety and Hazards Do not operate DoorKing wireless products in areas where cellular modems are not advised without proper device certifications. These areas include environments where cellular radio can interfere such as explosive atmospheres, medical equipment, or any other equipment which may be susceptible to any form of radio interference. DoorKing wireless products can transmit signals that could interfere with this equipment. Do not operate DoorKing wireless products in any aircraft, whether the aircraft is on the ground or in flight. In aircraft, DoorKing wireless products **MUST BE POWERED OFF**. When operating, DoorKing wireless products can transmit signals that could interfere with various onboard systems.

Note: Some airlines may permit the use of cellular phones while the aircraft is on the ground and the door is open. DoorKing wireless products may be used at this time.

The driver or operator of any vehicle should not operate DoorKing wireless products while in control of a moving vehicle. Doing so will detract from the driver or operator's control and operation of that vehicle. In some states and provinces, operating such communications devices while in control of a vehicle is an offence.

