II-M1500-28



M1510/M1520C FUNCTION CHANGE INSTRUCTIONS

FOR USE WITH THASE ENTERPRISE M2000 SERIES MORTISE LOCKS

Installation:

- 1. Remove the cover from the lock case.
- 2. Locate the solenoid body within the cutout of the solenoid locating plate:
 - A. For fail-safe(M1510C) function, the solenoid plunger should extend from the solenoid body toward the face plate of the lock.
 - B. For fail-secure (M1520C) function, the solenoid plunger should extend from the solenoid body toward the back of the lock.
- 3. Rotate the solenoid body within the cutout such that the lead wires are close to the solenoid plate.
- Failure to do so may cause the lead wires to interfere with the movement of the mechanism.
- 4. Route the lead wires along the body of the solenoid and under the clamp. Verify the lead wires are not interfering with the movement of the mechanism.
- 5. Attach the cover to the lock case.

