



MVE-SV010Q

VGA over Cat5e/6

Manual



- Passive operation—no external power required
- Uses inexpensive Cat5e/6 cable (UTP/STP)*
- Extends VGA cable range up to 197ft (60m) at 1280x1024 resolution

*Unit works with unshielded twisted pair (UTP) and shielded twisted pair (STP). For best results in areas with high interference, use STP.

SLI SECO-LARM



NOTE: Products with model numbers that end with "Q" or products that have a round green "Q" sticker signify RoHS compliance.

Introduction:

The ENFORCER Passive VGA Baluns extend VGA video signals up to 443ft (135m) using low-cost Cat5e/6 cable. These units make it possible for CCTV video sources such as DVRs and computers to be secured in one room while running VGA signals to a monitor or projector in another room.

Specifications:

VGA connectors		Female, 15-pin
Number of inputs		1
Number of outputs		1
Range	640x480 pixels (15MHz)	443ft (135m)
	800x600 pixels (30MHz)	344ft (105m)
	1024x768 pixels (60MHz)	246ft (75m)
	1280x1024 pixels (100MHz)	197ft (60m)
Operating temperature		32°~131° F (0°~55° C)
Operating humidity		Up to 95%
Storage temperature		-4°~185° F (-20°~85° C)
Dimensions		2 1/2" x 2 5/8" x 1" (64x67x27 mm)
Weight		10-oz (284g)


T568-B Wiring Specification:

Pair #	Wire	Pin #	Configuration
1	Blue	4	G Video (+)
	Blue/White	5	G Video (-)
2	Orange/White	1	R Video (+)
	Orange	2	R Video (-)
3	Green/White	3	Horizontal sync
	Green	6	Vertical sync
4	Brown/White	7	B Video (+)
	Brown	8	B Video (-)


Parts List:

- | | |
|-----------------|---------------------|
| 1 x Transmitter | 2 x Mounting Plate |
| 1 x Receiver | 8 x Plate Screws |
| 1 x Manual | 8 x Mounting Screws |

Dimensions:




Mounting Plate Installation:




Overview:

Transmitter:




Receiver:



Installation:


1. Determine the location where the VGA over Cat5e/6 units will be placed as well as how much Cat5e/6 cable will be necessary.
2. Connect the VGA source to the transmitter's "VGA Source" connector using a VGA cable.
3. Connect the VGA display or other destination device into the receiver's "VGA Monitor" connector using a VGA cable.
4. Connect the receiver and transmitter units using a Cat5e/6 cable.
5. If using Cat5e/6 shielded twisted pair (STP), ground the cable's shield to the ground screw on both units.
6. Adjust the sync mode switch (see below).

Sync Mode Switch:




1. For LCD monitors under 17" or CRT monitors, use sync mode 2. If there is no image, switch to sync mode 1.
2. For LCD monitors over 17", use sync mode 1. If there is no image, switch sync mode 2.
3. If there is still no image, see *Sync Balancing DIP Switch*.

Sync Balancing DIP Switch:



1. For CRT monitors, if no image appears, it may be necessary to adjust the sync balance.
2. If there is no image, turn on switch #1. Flip each switch one at a time until an image appears.
3. If each DIP switch setting has been tested but no image appears, it may be necessary to use shielded twisted pair (STP).

Sample Application:



² Unit works with unshielded twisted pair (UTP) and shielded twisted pair (STP). For best results in areas with high interference, use STP.

Troubleshooting

Image is weak, faded, or blank.

- Use shielded twisted pair (STP) cable.
- Check the sync mode switch.
- Check the sync balancing DIP switch.
- Check that the cable length is within the given limits of the resolution being used.
- Replace with a higher-grade cable. The balun works with Cat5, but Cat5e and Cat6 allow for longer range operation.
- Make sure the source and displays are powered.
- Make sure the transmitter and receiver are plugged into the correct units.

Also Available from SECO-LARM:



**Component Video Baluns
Over Cat5e/6**



HDMI over Cat5e/6



**Active VGA and Audio
Distributors over Cat5e/6**



HDMI Matrix



Wireless HDMI Extenders



HDMI Switcher

WARRANTY This SECO-LARM product is warranted against defects in material and workmanship while used in normal service for a period of one (1) year from the date of sale to the original consumer customer. SECO-LARM's obligation is limited to the repair or replacement of any defective part if the unit is returned, transportation prepaid, to SECO-LARM. This Warranty is void if damage is caused by or attributed to acts of God, physical or electrical misuse or abuse, neglect, repair, or alteration, improper or abnormal usage, or faulty installation, or if for any other reason SECO-LARM determines that such equipment is not operating properly as a result of causes other than defects in material and workmanship. The sole obligation of SECO-LARM, and the purchaser's exclusive remedy, shall be limited to replacement or repair only, at SECO-LARM's option. In no event shall SECO-LARM be liable for any special, collateral, incidental, or consequential personal or property damages of any kind to the purchaser or anyone else.

NOTICE: The information and specifications printed in this manual are current at the time of publication. However, the SECO-LARM policy is one of continual development and improvement. For this reason, SECO-LARM reserves the right to change specifications without notice. SECO-LARM is also not responsible for misprints or typographical errors. Copyright © 2012 SECO-LARM U.S.A., Inc. All rights reserved. This material may not be reproduced or copied, in whole or in part, without the written permission of SECO-LARM.

SECO-LARM U.S.A., Inc.

16842 Millikan Avenue, Irvine, CA 92606

Tel: 800-662-0800 / 949-261-2999 Fax: 949-261-7326

Website: www.seco-larm.com

E-mail: sales@seco-larm.com

 PITSW4

MVE-SV010Q_1208.docx