



WIRING FOR E7500 & SS7500 LOCKS:
 GO THRU DOOR AND NOT DEVICE.
 MINIMUM RACEWAY CLEARANCE IS 1/4"

LHR SHOWN
 RHR OPPOSITE

NOTE: MOUNTING HOLES TO BE PREPARED
 AT INSTALLATION ON DOOR
 FOR OUTSIDE TRIM PREPARATION, WHEN REQUIRED,
 SEE ADDITIONAL TRIM TEMPLATE

8875/8875-F Mortise Lock Device (Wood Door)

VON DUPRIN®

NOTES: SEE MASTER SHEET #10001 FOR SUGGESTED REINFORCING

TEMPLATE NUMBER: **W10179_a**

DATE: 05-29-13