



▶ **DOCUMENT NUMBER:**
2600-518-A-02-07

▶ **GROUP:**
TELEPHONE ENTRY

▶ **2600-584 Telephone Entry
Heater Kit Installation**

Installation Procedure

NOTE:

- Heater and thermostat come equipped with mounting magnets, no mounting hardware is required.
- Heater hardware will get very hot, do not allow the heater hardware to come in contact with existing components or wires.
- Do not power the heater from the telephone entry system power transformer.
- Thermostat turns heater on at approximately 40°F (4°C) and off at 55°F (12°C).

1. Attach the heater to the top of the cabinet.
2. Attach the thermostat on the opposite side near the bottom of the cabinet.
3. Route wires avoiding contact with the resistors.
4. Connect the heater and thermostat wiring to the transformer.
5. Use 18 AWG 600 volt insulated wire for heater power runs up to 100 feet. Use 16 AWG 600 volt insulated wire for heater power runs up to 200 feet.
6. Do not run heater power wires over 200 feet or use smaller wires than that specified.

