

ALARM LOCK 345 Bayview Avenue, Amityville, New York, U.S.A. 11701 For Sales and Repairs 1-800-ALA-LOCK • For Technical Service 1-800-645-9440 Fax: 631-789-3383 • info@alarmlock.com Note: Technical Service is for security professionals only

ALARM LOCK Tech Support



Date: Monday, September 26, 2011

- **Subject:** Door Prep for adding a standard 2¹/₈" boar auxiliary deadbolt located above most Alarm Lock Trilogy locksets
- Models: DL2700, DL2800, DL/PDL3000, DL3200, DL/PDL3500, DL/PDL4100, DL/PDL4500, DL5200, DL/PDL5300, DL/PDL6100 and DL/PDL6500

This chart can be used with the installation of most Alarm Lock locksets when an additional auxiliary deadbolt is required.

ALARM LOCK MODEL NUMBER	INSTRUCTIONS	MINIMUM CENTER TO CENTER
Standard 2 ¹ / ₈ " Bore Models: DL2700, DL2800, DL/PDL3000, DL3200, DL/PDL4100, DL5200, DL/PDL5300	Measure from the center of the Alarm Lock 1" diameter latch hole to the center of the aux deadbolt 21/8" hole.	8¼"
Mortise Lock Models: DL/PDL3500, DL/PDL4500	Measure from the center of the Alarm Lock mortise body to the center of the aux deadbolt 2 ¹ / ₈ " hole.	9¼"
Networx 2 ¹ / ₈ " Bore Models: DL/PDL6100	Measure from the center of the Alarm Lock 1" diameter latch hole to the center of the aux deadbolt 2 ¹ / ₈ " hole.	10¾"
Networx Mortise Lock Models: DL/PDL6500	Measure from the center of the Alarm Lock mortise body to the center of the aux deadbolt 2 ¹ / ₈ " hole.	11½"

Note: If the diameter of the auxiliary deadbolt plate is greater than 2¹/₂" you must increase the center-to-center dimensions accordingly.