

INSTALLATION INSTRUCTIONS K-106 AUTHORIZED EGRESS (AE) SWITCH KIT

FOR USE WITH ADAMS RITE 3000 AND 8000 SERIES EXIT DEVICES

Electrical Specifications:

Wire Leads: 22AWG
SPDT Monitor Switch:
Contact Rating: 4A @ 250VAC

Wire Color Codes:

Yellow Wire: Common
Red Wire: Normally Open
Gray Wire: Normally Closed

Installation:

1. Separate the push bar from the mounting bar assembly.
2. Locate the K-106 Kit near the rear push bar mechanism.
3. Rotate the switch plate clockwise to engage the upper mounting bar groove and slide toward the rear push bar mechanism. Verify the switch arm is positioned behind the center link flange.
4. Secure the switch plate to the mounting bar by tightening the set screws.
5. Route the lead wires along the side of the mounting bar, into the lower mounting bar groove, and under the pin.
6. Secure the lead wires to the mounting bar using the supplied ty-wrap mount and ty-wrap.
7. Attach the push bar to the mounting bar assembly.

SWITCH MONITORS PUSH BAR DEPRESSION

