DITEK IBNC INSTALLATION INSTRUCTIONS

APPLICATION: This device is intended for indoor or outdoor use and to connect in line with the coaxial cable.

- 1. Check the cable signal before and after the installation of the DTK-iBNC to insure proper hook-up and no signal distortion.
- 2. Disconnect the cable from the camera.
- 3. Using the patch cord supplied, connect the equipment (output) side of the iBNC to the camera input.
- 4. Reconnect the input cable to the iBNC input.
- 5. A separate ground is not required for the DTK-iBNC.

NOTE: The cable shielding must be grounded at the point it enters the building.

6. For further information or technical support please call 1-888-472-6100.

DITEK	Diversified 1	Гесhnology	Group,	lnc.

1720 Starkey Road Largo, Florida 33771 Tel. 727-812-5000 Fax 727-812-5026

Installation Instructions For Ditek iBNC								
MATERIAL:			APPROVED BY:					
FINISH:								
DRAWN BY:	DATE:	REVISED:	DWG NO.	PART NO.	REV.			
RWM	4-27-01	9-24-03	IiiBNC	191424	2			

DITEK IBNC INSTALLATION INSTRUCTIONS

APPLICATION: This device is intended for indoor or outdoor use and to connect in line with the coaxial cable.

- 1. Check the cable signal before and after the installation of the DTK-iBNC to insure proper hook-up and no signal distortion.
- 2. Disconnect the cable from the camera.
- 3. Using the patch cord supplied, connect the equipment (output) side of the iBNC to the camera input.
- 4. Reconnect the input cable to the iBNC input.
- 5. A separate ground is not required for the DTK-iBNC.

NOTE: The cable shielding must be grounded at the point it enters the building.

6. For further information or technical support please call 1-888-472-6100.

