

II - M1500-3

CORBIN RUSSWIN ML2055 ELECTRIC LOCK M1510/1520C FUNCTION CHANGE INSTRUCTIONS

TO CHANGE THE LOCKING FUNCTION FOLLOW THE
THE BELOW INSTRUCTIONS CAREFULLY.

STEP 1: REMOVE THE 3 COVER SCREWS AND COVER

**STEP 2: USING THE ILLUSTRATION BELOW, REMOVE PIN AND REPLACE PIN
IN PROPER HOLE AS FOLLOWS**

A FOR FAIL SECURE M1520C (POWER UNLOCK) FUNCTION

B FOR FAIL SAFE M1510C (POWER LOCK) FUNCTION

**STEP 3: REPLACE COVER AND SCREWS. MAKE SURE SOLENOID IS PROPERLY
POSITIONED IN COVER SLOT.**

A INSERT PIN HERE FOR FAIL SECURE
(POWER UNLOCK) OPERATION

B INSERT PIN HERE FOR FAIL SAFE
(POWER LOCK) OPERATION

