

TROUBLE SHOOTING

LED is not flashing*

- Check batteries

* Some models do not include flashing LED.

IMPORTANT:

Users and installers of this product are responsible for ensuring this product complies with all national, state, and local laws. SECO-LARM is not responsible for the use of this product in violation of any current laws or statutes.

SECO-LARM makes no warranties expressed or implied that dummy cameras will prevent any criminal or inappropriate activity. SECO-LARM disclaims any and all liability for any damages to property or persons as a consequence of the purchase or installation of dummy cameras. Neither SECO-LARM nor any of its officers, employees or resellers shall be subject to any liability arising out of or in connection with this sale. The purchaser assumes all risk and all liability arising out of the installation of dummy cameras.

WARRANTY:

This SECO-LARM product is warranted against defects in material and workmanship while used in normal service for a period of one (1) year from the date of sale to the original consumer customer. SECO-LARM's obligation is limited to the repair or replacement of any defective part if the unit is returned, transportation prepaid, to SECO-LARM.

This Warranty is void if damage is caused by or attributed to acts of God, physical or electrical misuse or abuse, neglect, repair, or alteration, improper or abnormal usage, or faulty installation, or if for any other reason SECO-LARM determines that such equipment is not operating properly as a result of causes other than defects in material and workmanship.

The sole obligation of SECO-LARM, and the purchaser's exclusive remedy, shall be limited to replacement or repair only, at SECO-LARM's option. In no event shall SECO-LARM be liable for any special, collateral, incidental, or consequential personal or property damages of any kind to the purchaser or anyone else.

NOTICE:

The information and specifications printed in this manual are current at the time of publication. However, the SECO-LARM policy is one of continual development and improvement. For this reason, SECO-LARM reserves the right to change specifications without notice.

SECO-LARM is also not responsible for misprints or typographical errors.

Copyright © 2008 SECO-LARM U.S.A., Inc. All rights reserved. This material may not be reproduced or copied, in whole or in part, without the written permission of SECO-LARM.

SECO-LARM® U.S.A., Inc., 16842 Millikan Avenue, Irvine, CA 92606

Tel: 800-662-0800 / 949-261-2999 Fax: 949-261-7326

Website: www.seco-larm.com

E-mail: sales@seco-larm.com

 PICS N1

MIDummyCamInf.pmd

Page 4

CBA®

Dummy Camera Series Installation Manual



Dummy IR camera
VD-30BS
(Shown)

SECO-LARM® U.S.A., Inc.

Dummy Camera Installation Manual

A SECO-LARM dummy camera is a great low-cost way to deter crime at home, the office, in parking lots, around parks and around playgrounds. The dummy camera creates the perception of electronic surveillance, without the high cost, high maintenance, and upkeep of cameras, monitors and DVR's.

Criminals are more likely to move on to an easier target if they know that there is a chance that they are being watched.

Our full line of dummy CCTV cameras means we have just the right camera for your particular needs. Mix the dummy cameras with real cameras to make the dummy cameras more believable.

Please read these instructions completely before installing:

1. Chose a suitable location. Usually, the higher up a dummy camera is, the more authentic it will appear.
2. Make sure the wires are inserted through the bracket and secured so they will not fall out over time.
3. For models with flashing LED, install 2 x AAA (or AA, depending upon model) batteries (batteries not included). To make it more realistic, do not install the batteries.
4. Be sure to mount the unit securely using the appropriate fasteners for your installation. Fasteners for basic installation are included.
5. Aim the unit at the desired location.

Note 1: This is an imitation camera, to be used as a deterrent only.

Note 2: For models with LEDs, if installed outdoors, do not install batteries.

Kit Includes:

- a. 1 Dummy Camera
- b. Hardware installation kit to mount camera

SECO-LARM Mounting Brackets Available:



VB-HC1 – Ceiling mount bracket for PTZ Speed Dome

- For model VD-40BN PTZ speed dome.
- 9" pipe with hole for easy access to wires.
- Threaded conduit fittings.

Other CBA Dummy Cameras - Model # and Description



VD-30BS – Dummy IR Bullet Camera

- Incorporates a realistic camera with video/power cables (one cable) to give it an authentic look.
- Metal mounting bracket included.
- Battery-powered LED.
- Requires 2 AA batteries (not included).
- Constructed of strong ABS plastic.



VD-20NN – Dummy Dome Camera

- Incorporates a realistic camera module to give it an authentic look.
- Constructed of strong ABS plastic.



VD-10BN – Dummy Security Camera

- Incorporates a realistic camera with a battery-powered LED to give it an authentic look.
- Includes simulated Video and power cable.
- Indoor / outdoor use.
- Metal mounting bracket included.
- Requires 2 AA batteries (not included).
- Constructed of weatherproof aluminum metal housing.



VD-40BN – Dummy PTZ Speed Dome Camera

- Incorporates a realistic camera with a battery-powered LED to give it an authentic look.
- Indoor / outdoor use.
- Weatherproof ABS plastic housing.
- Metal wall mount bracket included.
- Requires 2 AA batteries (not included).
- Threaded conduit fittings allow for extended mounting.



VD-10BNA – Dummy Box Camera

- Incorporates a realistic camera with video/power cables (one cable) to give it an authentic look.
- Battery-powered LED.
- Requires 2 AAA batteries (not included).
- Constructed of strong ABS plastic.