



DITEK Corporation
ONE DITEK CENTER
1720 Starkey Road
Largo, FL 33771

INSTALL INSTRUCTIONS

DTK-110C6A, DTK-110C6APOE

This Surge Protective Device (SPD) is a high performance device, designed to provide protection for sensitive electronic loads when the SPD is directly connected to the electronic device. Maximum protection will only be achieved if the SPD is properly installed.

Please read and follow the installation instructions carefully.

NOTICE: This SPD should be installed by a qualified electrician in accordance with the National and Local Electrical Codes and the following instructions.

APPLICATION

Surge suppression for IP, or PoE circuits transmitting video and/or data over CAT6 or CAT6A cable. The DITEK is wired in series and terminating with a 110 punch down Input/Output. For Power Over Ethernet (PoE) circuits, use DTK-110C6APOE. For non-PoE circuits, use DTK-110C6A

INSTRUCTIONS:

Caution: Measure all voltages to insure applied voltage does not exceed the voltage rating of the unit. Improper installation voids the warranty.
This unit must be connected in series with the equipment to be protected.

DISCONNECT CIRCUIT BEFORE BEGINNING INSTALL.

1. Remove screws and cover and save for later.
2. Terminate the incoming (field) wires to the IDC (110) punch down block, Input side.
3. Follow the wire color codes printed on the circuit board next to the IDC connectors for wire termination points.
T568A Wiring- BL-BL/W, BR-BR/W, OR/W-OR, GR-GR/W
T568B Wiring- BL-BL/W, BR-BR/W, GR/W-GR, OR-OR/W
This connector is rated for 26-22AWG solid conductor wire.
The wire pairs must be twisted together and maintain that twist all the way to the punch down block.
4. If using STP (Shielded Twisted Pair) , the shield must be connected to the "Shield" termination screw located on the circuit board near the IDC connector. This can be accomplished by twisting the shield into a wire and wrapping it under the screw.
5. Connect the wiring to the equipment to be protected to the IDC (110) punch down block, Output side. Repeat steps 2 and 3 above.
6. Always have one common ground per system to eliminate the possibility of a differential in ground potentials. The ground conductor should be a minimum #14 AWG wire. This wire should be shorter than the patch cords used to connect to the equipment to be protected to the DITEK. This wire shall be mechanically secured to the "Ground" termination screw located on the Input side of the circuit board near the IDC connector.
7. Using the velcro loops provided, secure the CAT6/CAT6A cabling to the circuit board.
Ground Resistance Rule: Max ground resistance is 25 Ohms, 5 Ohms or less is optimum. This cannot be an assumed value and must be measured to assure proper grounding.
8. After all connections have been made and no hazards exist, replace the cover and screws and restore the circuit.

INSTALLATION

DITEK Technical Support Available 24/7

1-888-472-6100

www.ditekcorp.com

Drawn By: R. Mitchell 3-15-13
Approved By: H. Tu 3-18-13

Doc # INT-100147-001
Part No. 191572 Rev. 1