

Owner's Manual

OIPC22T7G



speco technologies®

Directions

Be careful not to cause any physical damage by dropping or throwing OIPC22T7G. Especially keep the device out of reach from children.

Do not disassemble OIPC22T7G. No After Service is assumed when disassembled.

Use only the power adapter provided with OIPC22T7G.

Be careful to prevent moisture or water penetration into the unit. Particular attention is needed when installing OIPC22T7G. The screw holes for the installation screws and pipe should be maintained water tight during the whole life time of the product.

All the electrical connection wires running into the unit should be prepared so that water from the outside cannot flow into the unit through the surface of the wires. Penetration of the moisture through the wire for extended period can cause malfunction of the unit or deteriorated image.

Note

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generate, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures :

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into and outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help.

Caution

Any changes or modifications in construction of this device which are not explicitly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Revision History

Date	Revision	Details
2012-09-01	1.0	First manual revision creation.

Contents

Contents	4
1. Introduction.....	6
1.1. Overview	6
1.2. Specification	7
1.3. Applications of OIPC22T7G.....	9
2. Product Description	10
2.1. Contents	10
2.2. Product Preview	11
2.3. Physical description.....	12
2.4. Functional Description.....	12
3. On Site Installation	15
3.1. Ceiling or Wall Mounting.....	15
3.2. Embedded mount bracket	Error! Bookmark not defined.
4. Getting Started.....	17
4.1. PC Requirement.....	17
4.2. Quick Installation Guide.....	18
5. Trouble Shooting	Error! Bookmark not defined.
5.1. No power is applied.....	Error! Bookmark not defined.

- 5.2. Cannot connect to the Video **Error! Bookmark not defined.**
- 5.3. Windows Vista or Windows 7 **Error! Bookmark not defined.**
- 5.4. Technical Assistance **Error! Bookmark not defined.**

1. Introduction

1.1. Overview

The OIPC22T7G is a state-of-the-art, multi-codec (H.264, MJPEG) IP camera (or network camera) built with embedded software and hardware technology. It enables real time transmission of synchronized video of up to D1 and audio data. Remote clients can connect to OIPC22T7G for the real time video data through various client solutions running on PC or mobile phones.

1.2. Specification

Category	Sub-Category	Details			
Video	Compression	H.264/MJPEG			
	Resolution	NTSC : 704x480, 640x480, 704x240, 352x240, 176x112 PAL : 704x576, 640x480, 704x288, 352x288, 176x144			
Audio (Bi-directional)	Up	N/A			
	Down	N/A			
Network	Interface	RJ-45, 10/100 Mbps			
	Access network	Static, DHCP, PPP/PPPoE			
	Protocol	IPv4/6, TCP, UDP, IGMP, ICMP, ICMPv6 etc.			
I/O	Sensor In	1	NC, NO Selectable		
	Relay Output	1	N/A		
	RS-232C	N/A			
	Mic/Line In	N/A			
	Line Out	N/A			
	CVBS output	N/A			
Power Supply	PoE	N/A			
	DC Adaptor	12V DC adaptor (2A)			
Mounting	Wall or Ceiling				
Motion Detection	3 zones	Arbitrary shape with independent sensitivity			
Upgrade	Firmware upgrade over IP network				
Administration	Remote administration over IP network				
Client & Viewer	Web Viewer	Simple viewing over internet explorer			
	Speco-NVR	Standard CMS software			
	3rd Party CMS	Ask SPECO for details			
Dynamic IP support	DDNS support	Supported			
Security	Video/Audio stream encryption				
	ID and Password protection				

	IP filtering for restricting administrative access for audio and bi-audio	
Time management	Sync to PC	Synchronize to PC
	Manual	Manual time setting
	Internet Time Server	Synchronize to Time Server
	DLS	Day light saving
SDK support	Active-X	
	HTTP	
	Source filter	

1.3. Applications of OIPC22T7G

- Security surveillance (buildings, stores, manufacturing facilities, parking lots, banks, government facilities, military, etc.)
- Remote monitoring (hospitals, kindergartens, traffic, public areas, etc.)
- Teleconference (Bi-directional audio conference). Remote Learning, Internet broadcasting
- Weather and environmental observation

2. Product Description


2.1. Contents

The product package contains followings :

Contents	Description	Remarks
OIPC22T7G	IP camera OIPC22T7G main unit	
Power Adaptor	12VDC Adaptor	Optional item
CD	Software & User's Guide	
Quick Reference Guide	Quick installation guide	

2.2. Product Preview

2.2.1. Preview

OIPC22T7G	IP-Installer	CMS Software (Speco-NVR)
		
IP Camera	PC software to allocate an IP address to the IP Camera	PC software to view and record the A/V streaming data transmitted from IP camera. (Simultaneous support of up to 64 IP cameras)

2.3. Physical description

2.3.1. External View



Figure 2-1. External view of OIPC22T7G

2.4. Functional Description

- **DC 12V** : Power input for supplying 12V DC power.

- **Line Out**

Connect speakers with built in amplifier. Audio from remote site is output through Line out in bi-directional audio mode.

- **100Base-T**

100Mbps Ethernet connector (RJ-45). 2 LEDs on the Ethernet connector shows the status of OIPC22T7G as the followings:

- **Status LED (Dual Color - Red/Green)** : It will be lit in green or red depending on the status.
 - ① **Green** : Green color indicates that the camera is in normal operation mode. Continuous green indicates that data transmission is possible. Blinking green means that someone is connected to OIPC22T7G.
 - ② **Red** : Continuous or blinking red indicates that hardware is in abnormal condition.



Red/Green LED will be lit with red momentarily and it will be lit with green after a while when power is applied into OIPC22T7G

- **LINK/LAN LED (Orange)**

It will be lit with orange color when network cabling is all right. Blinking orange color indicates that normal data transmission is under way. Off state indicates that there is trouble in network connection.

- **ALARM IN/OUT and Composite Video Output**



Figure 2-3 ALARM IN/OUT and Composite Video Output Terminal of OIPC22T7G

Used for connecting P/T device, sensor, and composite video output. Pin assignments are as follows.

Pin	Description	Misc.
1	SNS IN (+)	Sensor In (+). NC/NO selectable in admin mode.
2	SNS In (-)	Sensor In (-). NC/NO selectable in admin mode.

- **SNS IN** : Examples of sensing devices are infrared sensors, motion sensors, heat/smoke sensors, magnetic sensor, etc. Connect the two wires of the sensors to "SNS In". The sensor type (NC/NO) can be set in Administrative mode. 10mA can be flown into sensor device. Multiple sensor devices can be connected in parallel.




Figure 2-4. SENSOR Input connection

- **Factory Default Switch**

A switch provided for returning the IP camera to factory default state. Open the cover to access the switch. Press the switch for a few seconds while power is applied.



Figure 2-6 Factory Default switch of OIPC22T7G



Caution: Restoring the factory default will erase all settings.

3. On Site Installation

3.1. Ceiling or Wall Mounting

Please follow through the procedures in the order of the numbers for each procedure.

1. Open dome cover as following.



2. Fix the product using 3 screws and anchors



3. Combine dome cover.



4. Getting Started

Brief information for first time operation of OIPC22T7G is provided in this chapter.

4.1. PC Requirement

Video streaming data received from OIPC22T7G can be displayed or stored in a PC running client programs. Minimum requirement of the PC is described below:

	Recommended	Remark
CPU	Dual Core 3Ghz 3G above	
Main Memory	2GB above	
Operating System [*]	Windows XP	
Web Browser	Internet Explorer 8.0 above	
Graphic Card	256M above	Higher than 1600x1200
Network	100 Base-T Ethernet	

* Operating Systems supported : Windows 2000 Professional / XP / Vista / 7

4.2. Quick Installation Guide

1. Connect PC and OIPC22T7G to network.

- 1) Prepare a PC to run programs for the installation and video connection
(PC is needed to assign IP address to OIPC22T7G)
- 2) OIPC22T7G as shown in dotted line in Figure 4-1. The DC power is applied through DC adaptor.



Figure 4-1. Power and network connection

Install “IP installer and set IP parameters on OIPC22T7G

Insert the CD provided with product into the PC. Install WinPcap and IP Installer in sequence. Make sure that IP Installer can't run without WinPcap.



IP installer Ver. **3.0.1 or later** is needed in the configuration of OIPC22T7G.

Follow the sequence below for setting the IP parameter

- i) Run IP installer > Select Network Adaptor >OK
- ii) Click ① in IP installer window.> Double click on ② > Fill in ④ > make a selection in ⑤ > Fill the parameters in ⑥
- iii) Click on ⑨ to apply the settings.
- iv) You can connect to admin page by clicking on ⑩

2. Install Speco-NVR

Speco-NVR is a multi-channel CMS program for to IP camera or Video server. Install Speco-NVR on remote PC to connect to these products. It is needed to assign connection information to Speco-NVR program before connection.

Insert the CD provided with product into the PC and install the Speco-NVR.





Figure 4-2. Speco-NVR

Follow the sequence below for setting the IP parameter

- v) Run IP installer
- vi) Click ① in IP installer window.> Double click on ② > Fill in ④ > make a selection in ⑤ > Fill the parameters in ⑥
- vii) Click on ⑨ to apply the settings.
- viii) You can connect to admin page by clicking on ⑩.



Click on the field in ③ for sorting and rearranging the list.

Select network mode that best suits from the drop down list in ⑤. You can choose either Static or ADSL and Auto (DHCP), respectively. If ADSL and Auto are selected, the fields in ⑥ is deactivated.

In case of ADSL, fill the User Name and Password in ⑧ with the values provided by your ISP.


If DDNS service is needed, Check at the box and fill the empty field with hostname you want in ⑦.



3. Remote video connection to ONSIP O2D3

1) Connection through Web Viewer

Web Viewer offers simplest way of video connection to ONSIP O2D3 . For video connection, enter the IP address of ONSIP O2D3 in the URL window of Internet Explorer as:



Note : Active-X module should be installed on your PC before actual connection. If your PC is not connected to the internet, you cannot download Active-X module. Most convenient way of installing the Active-X module is installing Speco-NVR which is available from the CD or our web site.



Connection to Admin Page

Basic Control




Figure 4-3. Web Viewer

Default ID and password of Admin Page are **admin, 1234**. For more detailed information, please refer to the [\[Configuration_Guide\]](#) Guide.

2) Connection through Speco-NVR

Click the camera assignment button for setting camera address. Input the description, address, Ch#, User ID, Password and port and then click the save button. After assignment procedure, you must click the SAVE button. You can see the live video when you click the live view button as below. When you exit Speco-NVR, you have to input the ID/PW, admin/1234. Details for the Speco-NVR can be found in **[Speco-NVR User's Guide]**.




Figure 4-4. Speco-NVR

4. Additional settings through connection to the Admin Page

All the parameters of new IP camera follows factory default values. For more sophisticated target application it is needed to change parameters. The admin page can be connected through

"http://IP address:HTTP port number"/admin.htm

It is needed to enter ID and password of the administrator. Default ID and password are **admin, 1234**. It is highly recommended to change the ID and password to prevent illegal access to the IP camera. For more detailed information, please refer to the **[Configuration_Guide]** Guide.

5. Trouble Shooting

5.1. No power is applied

- In case of DC adaptor

If PoE is not applied, the power and network connection should be made through separate cables.


It is recommended to use DC adaptor supplied by provider for the feeding of the power. In case of replacing the DC power supply, make sure that the power supply meets with the power requirement of the IP camera to prevent damage or malfunction.

5.2. Cannot connect to the Video

Check the status of the network connection through PING test.

Try the following on your PC :

- Start > Run > Cmd > Ping IP address (Ex : Ping 172.16.42.51)
- If “Reply from ~” message is returned (① in the figure below), the network connection is in normal state. Try connection to the video again. If the problem persists, or refer to other trouble shooting notes.
- If “Request timed out” message is returned. (② in the figure below), the network connection or network setting is not in normal state. Check the network cable and settings.




5.3. Windows Vista or Windows 7

Windows Vista and Windows 7 users need to configure UAC (User Access Control) and Privilege Level for proper recording and still video capture in Speco-NVR and Web Viewer.

<Windows Vista>


1. UAC (User Access Control) configuration

- 1) Double-click "User Accounts" in control panel
- 2) Double-click "Turn User Account Control on or off"
- 3) Uncheck "Use UAC to help protect your computer"



2. Privilege Level Control


- 1) Select "NVR" icon on the desktop
- 2) Click right mouse button and select "Properties"
- 3) Check "Privilege Level" in "Compatibility" tab



<Windows 7>


1. UAC (User Access Control) configuration

- 1) Double-click "User Accounts" in control panel
- 2) Double-click "Change User Account Control setting"
- 3) Set to "Never notify"



2. Privilege Level Control

- 1) Select "NVR" icon on the desktop
- 2) Click right mouse button and select "properties"
- 3) Check "Privilege Level" in "Compatibility" tab



5.4. Technical Assistance

If you need any technical assistance, please contact your dealer. For immediate service please provide the following information.



- 1. Model name**
- 2. MAC address and Registration number**
- 3. Purchase date**
- 4. Description of the problem**
- 5. Error message**